Convotherm 4 easyTouch - Quick Reference Guide for Fully Automatic Cleaning

▲WARNING

Contact with cleaning agents

▲WARNING

Hot surfaces

▲WARNING

Spraying water inside while the

Risk of chemical burns and skin, eye, and respiratory tract irritation


Risk of burns when there are high temperatures on the inside and at the combi oven vents

oven is hot


Risk of scalding posed by hot steam

Open/empty the oven





Check cleaning



Close the unit door

Check connections





Select a cleaning



Select a cleaning

level



Select a mode






Confirm





Check the inside







Cleaning will start







Drying in progress Cleaning done -- please wait please confirm



Open the unit door/



easy TOUCH Weekly manual cleaning:



Clean oven drain



Leave unit door ajar



Legend:











/<u>1\</u>



Level 2 - medium

Level 3 - heavy





regular - medium/medium






eco - low/slow














- 1) Fan screen
 - Clean by hand with a slightly damp cloth and common household dishwashing liquid
- 2) Hygienic removable gasket
 - · Wipe clean by hand using a soft cloth and common household dishwashing liquid
 - · Wipe clean with a soft cloth and water

- 3) Door drip tray
 - Clean by hand using a soft cloth and common household dishwashing liquid
 - Wipe clean with a soft cloth and water

These instructions are meant to supplement the operating manual for your unit and should only be used together with it while observing all safety information and instructions.

