



## Equipex Panini Grill Cleaning Procedures

1. Turn Grill Off and allow cooling before cleaning.
2. Using provided grill scraper, remove as much debris as possible from the plates. Clean the top plate first, then the bottom, scrapping debris into front drip trough.
3. Remove Drip Trough and Rear Handle Cover. Clean area at rear of grill surface and around handle brackets to remove all remaining debris. Be sure to remove any build up in back of grill to prevent problems with closing grill while cooking.
4. If needed, tighten handle bracket screws to adjust lid tension.
5. As unit displays carbon buildup, use a cleaning product such as "Carbon Off" to help remove. Be sure to follow the instructions carefully and thoroughly clean grill after using this product with designated method. After cleaning be sure to reseason the grill for best performance.
6. Wipe down the exterior of the unit using a soft cloth with soapy water.  
**Do not spray unit or immerse in water.**

